CODING A REMOTE CONTROL INTO A TEMPO OR SYNCRO OPENER

tip

The opener can only be operated from remote controllers that have been programmed into its memory. Up to 64 remotes can be programmed.

STEP ONE

Switch power on and remove controls cover

STEP TWO

MODE

Press repeatedly

till remote LED lit

STEP THREE

HOLD

Opener flashes & beeps

HOLD for 3 sec

RELEASE

HOLD for 3 sec

Release both buttons

STEP FOUR

MODE

OFF

Then replace controls cover

STEP FIVE

Press to test

REMOTELY CODING A REMOTE CONTROL

tip

Remotely coding works when you have a pre-coded remote control and are in range of the opener.

STEP ONE

Take a pre-coded remote and press the button to duplicate

STEP TWO

Use a pen,

HOLD for 2 sec

the middle button through the coding hole

STEP THREE

Opener flashes & beeps

Take new remote

HOLD for 3 sec

RELEASE

HOLD for 3 sec

RELEASE

STEP FIVE

Opener stops flashing & beeping

Press to test

CHANGING A BATTERY

tip

Battery Type: 1 x CR2032.

STEP ONE

HOLD

Check Light Status Table

Light Status	Battery
Solid	OK
Flashing	Replace
No light	Replace

STEP TWO

Use screwdriver to remove scews and open

STEP THREE

Use non-metallic object to push out.

WARNING!: The battery is hazardous and must be kept out of reach of children. The battery can cause severe of fatal injuries within 2 hours or less if swallowed or placed inside any part of the body. If you suspect the battery has be swallowed or placed inside any part of the body, SEEK IMMEDIATE medical attention.