
CODING A REMOTE CONTROL INTO A TORO

The opener can only be operated from remote controllers that have been programmed into its memory. Up to 511 remotes can be programmed.

CODING A REMOTE CONTROL INTO OPENER

STEP ONE



remove screws & cover to access buttons

STEP TWO



Press to Navigate to Menu 1



Press to enter coding

STEP THREE

Controller will prompt to press



HOLD for 3 sec
RELEASE
HOLD for 3 sec
RELEASE

STEP FOUR



Press



Press to test

refit cover & secure with screws

REMOTELY CODING A REMOTE CONTROL


Remotely coding works when you have a pre-coded remote control and are in range of the opener.

STEP ONE



Take a pre-coded remote and press the button to duplicate

STEP TWO



Use a pen,
HOLD for 2 sec
the middle button through the coding hole

STEP THREE

Opener flashes & beeps



Take new remote

HOLD for 3 sec
RELEASE
HOLD for 3 sec
RELEASE

STEP FIVE

Opener stops flashing & beeping



Press to test

CHANGING A BATTERY

Battery Type: 1 x CR2032.

STEP ONE

Check Light Status Table

HOLD


Light Status	Battery
Solid	OK
Flashing	Replace
No light	Replace

STEP TWO



Use screwdriver to remove scews and open

STEP THREE



Use non-metallic object to push out.

WARNING!: The battery is hazardous and must be kept out of reach of children. The battery can cause severe of fatal injuries within 2 hours or less if swallowed or placed inside any part of the body. If you suspect the battery has be swallowed or placed inside any part of the body, SEEK IMMEDIATE medical attention.