



VIPP HEADQUARTERS
Snorresgade 22 | 2300 Copenhagen S | Denmark
+45 4588 8800 | info@vipp.com

VIPP STUDIO USA
+1 917 580 2148 | vippusa@vipp.com

VIPP.COM | @VIPP

vipp



VIPP718/VIPP19
Open-Air Table

**CONGRATULATIONS ON YOUR NEW
VIPP OPEN-AIR TABLE**

Whether we develop a bin, rethink
the modular kitchen, or create a furniture
line, we measure the quality of our products
on their ability to stand the test of time.
A recipe we have followed since 1939.

KASPER EGELUND, CEO AND 3RD GENERATION VIPP OWNER

Nestled in the industrial design tradition, the Vipp table is designed to withstand the test of time in both function and aesthetics. The Vipp718/Vipp719 Open-Air table is 2.5/1.57 meters long and consists of an aluminum frame with a 12 mm ceramic tabletop. The legs are conical and made of teak wood. Small adjustable feet are to be found underneath each leg, allowing to adjust the height of the table depending on the surface.

Materials


Tabletop of ceramic. Outdoor coating. Frame with aluminum and teak conical table legs fitted with screws in stainless steel.

Weight

Vipp718 56 kg / 123.5 lbs Vipp719 88 kg / 202.8 lbs

PRODUCT DIMENSIONS

Vipp718 W. 100 cm / 39.4 in, L. 157 cm / 61.8 in, H. 74 cm / 29.1 in.




Vipp719 W. 100 cm / 39.4 in, L. 250 cm / 98.4 in, H. 74 cm / 29.1 in.



Please follow the installation guide to ensure correct installation.

1. When assembling your table, place it upside down on the cardboard or another soft underlay to prevent scratches or marks and to protect the floor. Do not place the table on its sides.
2. Mount all legs (a), and tighten the top screw on each leg (b).
3. Flip the table carefully, placing it on its feet. Adjust the height of the table using the adjustment screws.
4. Place tabletop carefully on the frame so it is aligned correctly on all four corners.



If you experience problems, please do not hesitate to contact our Customer Service at info@vipp.com.

MAINTENANCE GUIDE

Daily use

We recommend caring for the table to ensure its long-lasting appeal and appearance.

Use a cloth, warm water, and a mild detergent. Use a slightly rougher sponge for solid stains on the tabletop and use a teak cleaner on the teak legs.

Protective cover

The protective cover is treated to resist water, oil, and dirt, functioning to protect the furniture.

The cover is not recommended as a permanent cover for the table and chairs, as moisture may collect and lead to the formation of mold stains.

Table and cushions should be thoroughly dry before being covered for an extended period.

Please note that the cover is specially made for the table and chairs and therefore correct placement is needed. To increase the circulation of air and avoid the formation of condensation, the cover is not made to floor length.

Never pack or fold covers that have become wet; instead, let them dry in a well-ventilated place.

Use a soft cloth and warm water to clean the covers, using a gentle upholstery cleaner if necessary. Rinse with clean water. Solvents are not suitable for cleaning the covers as these are aggressive to the surface and may cause damage and discoloration.

We recommend caring for the tabletop to ensure its long-lasting appeal and appearance.

Ceramic tabletop

General care: Use a cloth, warm water, and a mild detergent. Use a slightly rougher sponge for solid stains.

Lime stains: Use a lint-free cloth and a mild detergent suitable for painted surfaces. Rinse with water and wipe down the frame with a dry cloth.

Grease stains: Use alcohol or glass cleaner to remove grease stains.

NOTE

Due to the hardness of the ceramic surface, please use caution when placing delicate items directly on the tabletop.

Teak wood

Teak will over time patina as it weathers.

Use a brush to remove any built-up dirt from the surfaces. Make sure to follow the natural grain direction to avoid scratches. Carefully dampen the teak surfaces with clean water and a lint-free cleaning cloth. Use a teak cleaner and evenly wash all surfaces with a soft cloth. Follow the instructions of the teak cleaner before cleaning it; use a sponge in the grain direction to avoid scratches. Lightly rinse surfaces with clean water and allow it to dry.

Powder-coated surfaces

Keep powder-coated surfaces clean and dry. Use a lint-free cleaning cloth or a soft brush with warm water and a mild detergent. Finish by wiping down the surface with a dry cloth.

Read more about care instructions on vipp.com.

WARRANTY

Vipp offers warranty on products according to national laws and regulations. The warranty does not cover defects or damage caused directly or indirectly by misuse or poor maintenance, violence or manipulation. The warranty presupposes rightful use as described in Vipp's care instructions, which can be found in this folder or under the specifications of each product at vipp.com. In case of a defective product, please contact your place of purchase.